



Serial Number:018TEES118

Model Number:H50RDC9AA2AN

- 1 Power/Volume Level
- 2 Push To Talk (PTT)
- 3 Side Button 1 Short Press: Battery Indicator
Side Button 1 Long Press: Unassigned
- 4 Side Button 2 Short Press: Unassigned
Side Button 2 Long Press: Unassigned
- Long Press Duration (ms): 2500
- 5 Channel Aliases

- 1 Pers1
- 2 Pers2
- 3 Pers3
- 4 Pers4
- 5 Pers5
- 6 Pers6
- 7 Pers7
- 8 Pers8
- 9 Pers9
- 10 Pers10
- 11 Pers11
- 12 Pers12
- 13 Pers13
- 14 Pers14
- 15 Pers15
- 16 Pers16



6 LED Operation Summary

LED Event	Comments
Scan	Blinks green during scan
Tx	Solid red while Tx
Busy	Blinks red when channel is busy
Call Decode	Blinks yellow upon receiving a call
Power up	Flashes green once upon successful power up
Low Battery Tx	Blinks red low battery during Tx
Good Battery LED	Solid green indicate good battery status upon press and hold of assigned button
Fair Battery LED	Solid yellow to indicate fair battery status upon press and hold of assigned button
Low Battery LED	Blinks red to indicate low battery status upon press and hold of assigned button
Poor Battery LED	All LEDs off to indicate poor battery status upon press and hold of assigned button

LIGHTHOUSE COMMUNICATIONS
27049 Santa Clarita Rd.
Saugus, CA. 91350
Contact: Kerwin Romero

"Guiding You To Communicate"

Phone: (818) 571-9738
Fax: (661) 297-6417
E-Mail: Rentals@CommunicationsEquipment.net
Web Site: <http://www.CommunicationsEquipment.net>